


ALPHA

# U81C Installation Guide

Oct, 2004

X001ZF1V-B


*U81C-60C*  
For Opteron, Athlon64



SEE U81C-60C FOR DRAWING

of the processor.

Begin to tighten the shoulder screws. Only tighten the screws a few turns each time, alternating between screws. Once the shoulder screw's stop makes contact with the standoff the shoulder screws will no longer turn. At this point, stop. Overtightening will not improve performance and may damage the shoulder screw or backing plate.



SEE U81C-60C FOR DRAWING

**FINAL ASSEMBLY AND INSPECTION**

If not already done, reinstall the MB inside the case. The U81C should now be fully assembled.

Inspect the heat sink to ensure that it is sitting level relative to the processor and socket. Make sure that the heat sink is not interfering with any part of the MB or case.